## Vehicle and IID Weatherization



## Take the following steps to ensure that your device is ready to be activated when it is time to leave:

- 1. Keep your vehicle parking in a garage, carport, or other area where it will be as protected as possible from the wind, ice, and snow. This will keep both the interior of your car and your device warmer.
- 2. In states where the device is enabled with Sleep Mode, put your device into this mode to conserve energy while your car is off for long periods of time. Just remember that while this conserves energy, you will need an extra minute to take the device out of Sleep Mode.
- 3. Before activating the device, take a minute to blow a few warm breaths slowly through the device. Then push the button to activate. This helps to physically warm the device up before turning the power on.

## Tips for subzero temps

Much like extremely hot temperatures, extremely cold weather will also impact electronics. Here are a variety of options to keep your device insulated.



**CLEAN WOOL SOCK** 



**HAND TOWEL** 



THERMAL GLOVE



**OVEN MITT** 

